










# Quick-Finder School balances

Readout [d] g	Weighing range [Max] g	Model KERN	Catalogue price excl. of VAT ex works €	Quality code	 1 DAY								
0,001	100	EMB 100-3		AA	1			•				•	○
0,001	200	EMB 200-3		AA	1			•				•	○
0,001	200	EMB 200-3V		AA	1			•	•			•	○
0,001	300	EMS 300-3		AA	1			•		•		•	•
0,01	200	EMB 200-2		AA	1			•				•	○
0,01	500	EHA 500-2		AA	1			•		•		•	•
0,01	500	EFS 500-2		AA	1			•				•	○
0,01	600	EMB 600-2		AA	1			•				•	○
0,01	1000	EMB 1000-2		AA	1			•				•	○
0,01	2000	EMB 2000-2		AA	1			•				•	○
0,01	2000	EMB 2000-2V		AA	1			•	•			•	○
0,01	3000	EMS 3000-2		BA	1			•		•		•	•
0,1	220	EFS 200-1S05		AA	1			•				•	○
0,1	500	EMB 500-1		AA	1			•				•	○
0,1	500	EMB 500-1BE		AA	1			•				•	○
0,1	500	EHA 500-1		AA	1			•		•		•	•
0,1	620	EFS 600-1S05		AA	1			•				•	○
0,1	1000	EHA 1000-1		AA	1			•				•	•
0,1	1200	EMB 1200-1		AA	1			•		•		•	○
0,1	3000	EMB 3000-1		AA	1			•				•	○
0,1	3000	EFS 3000-1		AA	1			•				•	○
0,1	3000	EHA 3000-1		AA	1			•		•		•	•
0,1	6000	EMB 6000-1		AA	1			•				•	○
0,1	6000	EMS 6K0.1		AA	1			•		•		•	•
0,1	12000	EMS 12K0.1		BA	1			•		•		•	•
1	2200	EFS 2000-0S05		AA	1			•				•	○
1	2200	EMB 2200-0		AA	1			•				•	○
1	3000	EHA 3000-0		AA	1			•		•		•	•
1	5000	EFS 5000-0S05		AA	1			•				•	○
1	5200	EMB 5.2K1		AA	1			•				•	○
1	6000	EMS 6K1		AA	1			•		•		•	•
1	12000	EMS 12K1		AA	1			•		•		•	•
5	5200	EMB 5.2K5		AA	1			•				•	○

• = standard ○ = option

## X Y Quality

X= stability quality feature (a high level of stability of the balance allows rapid & repeatable weighing result)  
 Y= dosing level quality feature (based on several parameters, indicate how-well suited a model is for fine dosing)  
 Level A, B or C, **C is the best level**



### Package shipment

The time required for internal shipping preparations is shown in days in the pictogram



### Verification possible



### Internal adjusting

Quick setting up of the balance's accuracy with internal adjusting weight (motordriven)



### Adjusting program CAL

For quick setting up of the balance's accuracy. External adjusting weight required



### Data interface RS-232

To connect the balance to a printer, PC or network



### Piece counting

Reference quantities selectable. Display can be switched from piece to weight



### Weighing with tolerance range

(Checkweighing) Upper and lower limiting can be programmed individually, e.g. for sorting and dosing. The process is supported by an audible or visual signal, see the relevant model



### Battery operation

Ready for battery operation. The battery type is specified for each device



### External power supply

Universal use